



# Bob Smith<sup>®</sup> Coachworks<sup>inc</sup>

*complete exotic and vintage automobile restoration*

7/8/14

Inv. A

Job#: JL-205

Re: Alfa Restoration

QTY.	MATERIALS	PRICE	AMOUNT
1	Hunter's Towing 7/8/014 DFW Airport to John Lee's Cedar Springs Rd.	\$ 700.00	\$ 700.00

<b>TOTAL DUE PLEASE PAY THIS AMOUNT</b>	<b>\$ 700.00</b>
---	------------------



# Bob Smith<sup>®</sup> Coachworks<sup>inc</sup>

complete exotic and vintage automobile restoration

9/11/14

*paid  
9-12-14  
wire transfer*

[Fax](#) Inv. B  
[Phone](#) Job#: JL-205 Re: Alfa Restoration

QTY.	MATERIALS	PRICE	AMOUNT
122.62	Hour/Labor	\$ 90.00	\$ 11,035.80
1	UPS Shipping-MoMa	\$ 20.73	\$ 20.73
1	Hunter's Towing-Bring Alfa to Gainesville	\$ 403.00	\$ 403.00
53	Sq Ft- Leather	\$ 7.00	\$ 371.00
1	B&R Shop- machine fittings	\$ 85.00	\$ 85.00
1	UPS Shipping-Lucas Tires	\$ 152.33	\$ 152.33
1	Miscellaneous Charges	\$ 1,103.58	\$ 1,103.58
			\$ -
			\$ -
<b>TOTAL DUE PLEASE PAY THIS AMOUNT</b>			<b>\$ 13,171.44</b>

## EXPLANATION OF WORK PERFORMED

Remove footpad, tail light  
kill switch, license plate bracket.  
Installed fire ex bracket.  
Work out ground strap.  
Installed crank rod.  
Work out tail light wire.  
Work out hood badge & seatbelts.  
Striped & blasted fenders.  
Weld license plate frame.

Northstar Bank of Texas  
Bob Smith Coachworks  
Acct #1140752  
Route #111904817  
Phone # 940-591-1200

Strip wheels & start blasting wheels.

Start degreasing engine bay & underside of car.

Check on temp gauge and work out details.

Figure leather.

Strip grill.

Install noise badge.



# Bob Smith<sup>®</sup> Coachworks<sup>inc</sup>

complete exotic and vintage automobile restoration

9/29/14

Tax Exempt #P12-870

Inv. C  
Job#: JL-205  
Re: Alfa Restoration

*Paid  
10-1-14  
wire transfer*

QTY.	MATERIALS	PRICE	AMOUNT
146	Hour/Labor (thru 9/25/14)	\$ 90.00	\$ 13,140.00
1	UPS Shipping-Lucas Tires	\$ 61.35	\$ 61.35
1	B&R Shopworks-Tach drive	\$ 85.00	\$ 85.00
4	Restoration Supply-Buckle #49	\$ 5.50	\$ 22.00
8	Restoration Supply-Footman loop	\$ 4.25	\$ 34.00
1	Miscellaneous Charges	\$ 1,314.00	\$ 1,314.00

<b>TOTAL DUE PLEASE PAY THIS AMOUNT</b>	<b>\$ 14,656.35</b>
---	---------------------

## EXPLANATION OF WORK PERFORMED

Wet sand fenders & straps.  
Fender bolts, stripping bolts, alimites  
Castle nut wire holes/dash  
Blast wheels, clean suspension on car.  
Blow car off and wipe down.  
Blast grille & wheels. Tape inside hub on  
wheels to be ready for prime.  
Scrap off old paint and sand with 400 grit to be  
ready for paint.  
Scrape loose paint off of suspension parts and  
prep for paint. Set up wheels & prep for prime.  
Tape car for paint.  
Strip dash of paint and sand blast. Mask and cover  
car with plastic.  
Blast crank handle. Finish taping car, hanging  
parts and prep for paint, clean tires.  
Take pictures & download of gauges.  
Remove cam cover & speedo. Drive & check

Northstar Bank of Texas  
Bob Smith Coachworks  
Acct #1140752  
Route #111904817  
Phone #940-591-1200

on parts needed, make drawing of tach  
pieces needed.

Figure on tach, make wooden sample, test fit,  
and scrap gaskets.

Unhook gauges.

Unload tires check wheels & valve stems &  
wire brush valve stems.

Spray primer.

Epoxy primer all 5 wheels, hung wheels.

Mask & tape car, wet sand and blocked fenders.

Painted fenders and other areas on car.





# Bob Smith<sup>®</sup> Coachworks<sup>inc</sup>

complete exotic and vintage automobile restoration

10/9/14

Tax Exempt #P12-870

Inv. D  
Job#: JL-205  
Re: Alfa Restoration

*paid  
10-14-14  
wire transfer*

QTY.	MATERIALS	PRICE	AMOUNT
130.5	Hour/Labor (thru 10/8/14)	\$90.00	\$11,745.00
0.042	Nickle Chrome	\$150.00	\$6.30
1	Mo-Ma- temperature gauge	\$375.00	\$375.00
1	Mo-Ma-shipping	\$25.00	\$25.00
1	Miscellaneous Charges	\$1,174.50	\$1,174.50

<b>TOTAL DUE PLEASE PAY THIS AMOUNT</b>	<b>\$13,325.80</b>
---	--------------------

## EXPLANATION OF WORK PERFORMED

Photograph interior & download pics.  
Remove interior from car & tear down  
seats & side panels & begin cleaning  
glue out of car.  
Fenders and remove gas pedal &  
Install to make for stone guard coating.  
Install block castle nuts.  
Countersink foot loops, spare tire,  
windshield, buckles & mirror.  
Scotch brite wheels. Put old  
tubes in tires and air up for tire  
to hold shape. Un-tape car, re-tape  
whole car halfway thru to paint  
springs, hangers etc.  
Continue mashing for paint, scotch  
brite and prep car.  
Finish scotch brite car, prep, wipe  
down and tach car for next round of paint.

Northstar Bank of Texas  
Bob Smith Coachworks  
Acct #1140752  
Route #111904817  
Phone #940-591-1200

Masking wheels for  
paint. Scotch brite wheels.  
Set up saw horses, wipe down and  
tack wheels for paint.  
Untape wheels and move outside to dry.  
Sand fenders & tape up for undercoating.  
Move wheels out to dry then back in.  
Buffing buckles & footman loops.  
Strip, dehead & B&B misc hardware.  
Download pictures & misc. Deheard stainless  
dash hardware, buff head & misc. Find screws  
for dash badge& install etc.  
Check on wire for black bolts.  
Unmask car and fenders. Cut down hung parts.  
Paint wheels and front grille.  
Hung fender, preped & clean.  
Spray undercoat.  
Untape fenders from spraying undercoat.  
Install fenders on car.  
Install lincense plate holder.  
Lay out hood belts.



# Bob Smith<sup>®</sup> Coachworks<sup>inc</sup>

complete exotic and vintage automobile restoration

10/29/14

Tax Exempt #P12-870

Inv. E  
Job#: JL-205  
Re: Alfa Restoration

*Paid  
10-30-14  
wire transfer  
\$ 14,783.75*

QTY.	MATERIALS	PRICE	AMOUNT
141.25	Hour/Labor (thru 10/27/14)	\$ 90.00	\$ 12,712.50
5	DLZ-dismount, mount & balance	\$ 75.00	\$ 375.00
1	B&R Shopworks-nuts for inner tube	\$ 425.00	\$ 425.00
1	Gebr. Van Der Sman-taillight	160euro	
1	Shipping-taillight	40euro	
1	Alum clamp	\$ 5.00	\$ 5.00
1	Miscellaneous Shop Supplies	\$ 1,271.25	\$ 1,271.25
		\$	-
<b>TOTAL DUE PLEASE PAY THIS AMOUNT</b>			<b>\$ 14,788.75</b>

## EXPLANATION OF WORK PERFORMED

Prep & install rivets in body where screws were.  
Peel leather off center hump in car.  
Make interior side panel patterns & cut & fit new aluminum panels.  
Install dash gauges & ignition switch.  
Hook up misc wiring, route tach cables & wiring through firewall & install grommets, clean old sealer off left engine head & install & seal up left valve cover & end cap & both tach drives. Make new gasket for water temp sender & install, scrape excess sealer off valve cover.  
Check fit of interior side panels & bend & sand tabs to hold them on & work out hardware.  
Fenders/lic plate  
Install valve stem nuts.  
Install grill.

Northstar Bank of Texas  
Bob Smith Coachworks  
Acct #1140752  
Route #111904817  
Phone #940-591-1200



Finish remove old glue from inside of car. Clean wheels to be ready to put back on car.

Remove old wheels, grease splines on hub and install newly painted wheels. Tape off bottom by hub on spare wheel.

Do sample of tie wire, check to see if matches what is on car.

Pick up tie wire.

Make & install rubber for floor.

Install snaps in rubber. Mayout leather and sew up side panels. Cover side panels.

Seat foam fabrication.

Sew up cover for seatback & install.

Mold interior alumimun panel to car.

Paint center front grille.

Touch up whole car. Paint radiator black.

Start making seat bottoms.



# Bob Smith® Coachworks .inc

complete exotic and vintage automobile restoration

11/25/14

Tax Exempt #P12-870

Inv. F

Job#: JL-205

Re: Alfa Restoration

*Paid  
12-2-14  
wire transfer*

QTY.	MATERIALS	PRICE	AMOUNT
132.65	Hour/Labor (thru 11/21/14)	\$90.00	\$11,938.50
1	Gebr. Van Der Sman-taillight	\$248.00	\$248.00
1	Phillip Cheaney-leather belts	\$500.00	\$500.00
1	Hunter's Towing	\$556.00	\$556.00
1	Miscellaneous Shop Supplies	\$558.85	\$558.85

<b>TOTAL DUE PLEASE PAY THIS AMOUNT</b>	<b>\$13,801.35</b>
---	--------------------

## EXPLANATION OF WORK PERFORMED

Re-route big tach cable, drill for side interior panel brackets & cut screws down to length & install in the car.  
Start & run engine.  
Install interior.  
Install seat belts.  
Install seats, put gas in car.  
Drive car & check over.  
Assemble & install tail lights.  
Cover car with plastic and scotch brite exhaust.  
Tape up and cover around exhaust and steering column for paint.  
Unmask car.  
Remove exhaust cover & blast.  
Move out and get ready to run, start & run.  
Unhook tach & remove tach to paint steering shaft.  
Get black on detail heat shield hardware B&B  
Sand oil tank cap & turn in lathe & scotch brite.

Northstar Bank of Texas  
Bob Smith Coachworks  
Acct #1140752  
Route #111904817  
Phone #940-591-1200

Install heat shield.

Install tach & make clamp.

Install side panels.

Hook up choke & get ready to start. Put fresh gas in, start & run, would not run right or idle, pulled air screen off & carb top off, remove squirter & clean. Start & run. Pulled jets off & cleaned. Installed, drained water out & install anti-freeze (did not have any). Start & run, let run for a while to circulate coolant.

Put carb screen on.

Put gas in & fuel additives.

Rear hood latches.

Finish fabricating foam on seat bottoms.

Begin laying out leather for bottoms.

Sew on seat bottoms. Install switch for fuel pump & route wiring.

Install covers on seat bottoms.

Install hood belts & move latches.

Oil spare tire belt.

Clean car.