

Lotus 47 Alignment / Corner Weight

9 Aug 2016

Initial weight w/ driver

LF 323 RF 340
_{798 778} 1578

LR 438 RR 475
_{(761) (815)}

Initial camber w/ driver

LF -1.1° RF -0.4°

LR +0.2° RR +1.1°

ADDED 5 GAL OF FUEL. 10 Aug 2016

LF 322 RF 350 42%

LR 475 RR 461 58%

49.6%

50.4%

TOTAL: 1608 (WITH DRIVER)

CROSS WEIGHT: 51.3%

TARGET:

LF
 333
 -11

RF
 339
 +11

LR
 464
 -11

RR
 472
 +11

TARGET

LF
~~320~~
 +3

RF
~~343~~
 +3

LR
 441
 +3

RR
 472
 -3